Pinnacle Sconce

INSTALLATION GUIDE

HANDMADE
IN U.S.A.

WEAR GLOVES
DURING INSTALL

FRAGILE FINISHES

DANGER: ELECTRIC SHOCK RISK. TURN OFF ELECTRICAL POWER BEFORE BEGINNING INSTALLATION AND USE CAUTION WHEN INSTALLING.

+1 212 334 7333

www.alliedmaker.com • sales@alliedmaker.com

1

Inspect Contents



Fixture

2x Machine Screw



Light Bulb

Terminology

Lock Ring



Universal Backplate

Fixture Socket

Adapter



Backplate



Junction Box

3

Unscrew the lock ring and carry the lock ring and the backplate away from the adapter.



4

Mount the fixture universal backplate to the junction box using the provided machine screws.



5

Connect the wires from the fixture to the wires from the junction box using wire nuts.



6

Carry the backplate back over the adapter and then screw the lock ring back onto the adapter to secure the backplate into place.



7

Screw the light bulb into the fixture socket.